



STEP 7: CABLE MANAGEMENT

- A. Route power and monitor cables through the flexible cable clips on the upper link (A).
- B. Slide the plastic cover on the lower link upward until it disengages, then remove (B).
- C. Route cables inside the lower link (C) and replace cover, slide downward until it clicks into place.
- D. Push cables into the flexible fingers of the cable management clip (D).



STEP 8: ADDING A SECOND ROW OF MONITORS


- A. Remove Top Cap from originally mounted post
- B. Attach second Post to top of first Post:
 - i. Posts must be fully seated against each other.
 - ii. Place Top Cap on top of second post.
- C. Repeat Installation step 4.



STEP 9: ADJUSTING M/FLEX CLAMP TENSION

MFlex arrives ready for use, however it may become necessary to adjust the clamp.

- A. Detach all monitors and arms from MFlex.
- B. Open the Lever (A) all the way.
- C. Turn the Adjustment Screw (B) clockwise ¼ of a turn using the 3mm Hex Key (C).
- D. Test your adjustments by closing the lever.



CAUTION: If the lever is difficult to close or will not close fully, it is over-tightened. Turn the Adjustment screw counter-clockwise slightly. Forcing it closed will cause damage to MFlex.

STEP 10: ARM ADJUSTMENTS

WEIGHT ADJUSTMENT

Your monitor should move up and down easily and stay in place once adjusted.

If the Monitor moves down from the adjusted position, or is hard to lift you should INCREASE the counterbalance tension.

If the Monitor rises up from the adjusted position you should DECREASE the counterbalance tension.

M2.1 AND M8.1 ADJUSTMENT

- A. Push the Upper Arm Link (A) downward until the Adjustment Screw (S) is visible.
- B. Using the 5mm Hex Key (M8.1) or the 4mm Hex Key (M2.1) turn the Adjustment Screw clockwise (towards +) to increase the load tension, and counter-clockwise (towards -) to decrease the load tension.

C. Turn the Adjustment Screw (S) until the Monitor is properly balanced.

D. Move the monitor around to ensure that the motion is smooth and the arm functions as intended and holding the monitor in place.

M10 ADJUSTMENT

A. To access the Adjustment Screw (S), use your finger to pry open the Cover (C) on the Upper Arm Link (A).

B. Using the 5mm Hex Key turn the Adjustment Screw clockwise to increase the load tension, and counter-clockwise to decrease the load tension.

C. Turn the Adjustment Screw (S) until the Monitor is properly balanced.






D. Move the monitor around to ensure that the motion is smooth and the arm functions as intended and holding the monitor in place.

E. Reposition the Cover (C) and press until it snaps into place.





CAUTION: Do not over-tighten the Adjustment Screws as it can damage the Arms.

Monitors Should Not Exceed:
 15.5 lbs for M2.1
 28 lbs for M8.1
 48 lbs for M10

Total Weight of All Monitor(s) Not To Exceed:
 60 lbs for M/Power or M/Connect
 95 lbs for Standard Base



MFLEX INSTALLATION HARDWARE




M/FLEX®
 Desk Mount
 Installation Instructions

STEP 1: ATTACH MOUNT TO WORK SURFACE

CLAMP AND GROMMET MOUNT


1A. For installation on open edge of work surface:

- Slide the Base with Clamp Mount (A) against work surface edge and fully tighten Clamp Screws (B) with 5mm Hex Key (C).




1B. For installation on work surface positioned against a wall or panel:

- Detach the Clamp Foot (E) from the Clamp Bracket (F) by loosening Bracket Screws (D) with 5mm Hex Key (C).
- Position the Clamp Bracket against work surface edge.
- Underneath the work surface, reattach the Clamp Foot to the Clamp Bracket using the Bracket Screws.
- Fully tighten the Clamp Screws (B) with 5mm Hex Key.




1C. For installation through a 3" grommet hole:*

- See step 1B – i to remove Clamp
- Position the Clamp Bracket (F) in Grommet Hole (G) and against the inside edge. Position Base (A) so that the front is facing the user.



iii. See steps 1B – iii, iv to reattach Clamp.

* If grommet hole is less than 3" a Bolt-Through mount is required.




CAUTION: Clamp Mounts cannot be used to mount the M8 to any vertical surface.

SLIDING DESK MOUNT

1D. For installation with minimal clamp clearance:


- Skip to step iii, if the Clamp Mount is not attached.
- Remove Base Cover (H) by lifting it off.
 - Using the 5mm Hex Key (C), loosen the three Base Screws (J) to remove Clamp Mount (K).
 - Loosely attach Sliding Clamp (L) to the Base Plate (M) with the Base Screws. Do not tighten these screws fully.
 - Slide the Clamp all the way onto the back edge of the work surface.
 - Fully tighten the three Base Screws.



BOLT-THROUGH MOUNT

1D. For installation on a work surface with no access for a clamp system:

- Skip to step iii, if the Clamp Mount is not attached.
- See steps 1B – i, ii to remove Clamp Mount
 - Remove the Post Bolt (N) from under the base using the 10mm Hex Key (O)
 - Pass the Bolt-Through Adapter (P) through the base and into the Post. Use the 16mm Wrench (S) to tighten the adapter.
 - Drill a hole (1/2" – 4") through the work surface in the desired location.**
 - Position the Base over the Hole (H).
 - Align Bolt-Through Plate (T), foam side up, under the work surface. Pass the Bolt (U) through the hole in the plate and screw into the Bolt-Through Adapter (P) using the 10mm Hex Key (O)
- ** The Bolt-Through Mount will accommodate holes and grommets up to 4" (102mm) in diameter. Holes 2" or larger will allow cables to be routed through before installation of the mount.




STEP 2: BRACKET ASSEMBLY AND CABLE CLIP

DUAL BRACKET CLAMP

2A. For Single and Dual Monitor applications.


- With the Lever (B) fully open, position the Dual Bracket (A) in desired location along the Post (C).
- Close the Lever fully.
- If you are using a second monitor, lift and remove the Cover (D).



TRIPLE MONITOR EXTENSION


2B. For Triple Monitor applications

- Remove the two set screws (E) that retain the Bracket Cap (F).
- Place the Extension Bracket (G) on top of the Dual Bracket facing the user, insert the Tabs (J) into the Pockets (K)
- Replace the Set Screws (E) and tighten until the Extension Bracket is secure and the screws are flush with the surface.
- Insert the Bracket Cap into the top of the Extension Bracket and push until it clicks into place.




CABLE MANAGEMENT CLIP

- Spread the Cable Management Clip around the Post in the desired location.
- Press the two sides together until Hoop (L) engages.
- To release, use fingernail to disengage Hoop.



STEP 3: SMART STOP ADJUSTMENT


Position the smart stop ring to limit the arm's range of motion. The marked angle will be in the center of the range of motion. The stop rings must be configured in such a way that the monitor does not pass behind the rear edge of the unit.



STEP 4: ATTACH ARMS TO BRACKET


Before adding each link, adjust the smart stop according to step 3. In a three link configuration, one must be a 4" link. The installation order of the links must not allow the monitor to pass behind the rear edge of the unit.

- Insert the first link into the mount until release button locks in place.
- Insert the second link into the straight link until release button locks in place.
- To remove link, press the release button and lift upward near the joint.



STEP 5: ATTACH VESA BRACKET TO MONITOR

- Remove the plastic top cover.
- Place VESA bracket in position on back of monitor with two cutouts (U) in vertical direction and attach using 4 screws provided. VESA bracket can accommodate 75mm or 100mm hole patterns. For this, you may also use screws that came with your monitor.
- If mounting space for 75mm VESA bracket is inset into back of monitor, place the 4 plastic spacers (S) between VESA bracket and monitor (align with hole pattern), and using the extended VESA screws (Y), attach through the spacers.
- Reinstall the plastic top cover.



STEP 6: ATTACH MONITOR TO ARM

Hold the monitor angled back, lower it to the arm. Align the VESA Bracket with the Arm and fit the Hook into the corresponding cutout in the VESA Bracket. Tilt the bottom of the monitor back until the Quick Release Tab on the arm snaps into position.

To remove the monitor, lift the Quick Release Tab and pull the bottom of the monitor away from the arm, then lift free of the hook.

NOTE: If needed, adjust tension screws (A) to hold monitor in desired position.

